

CONVEX SECURITY MIRRORS

J-BRACKET INSTALLATION



INSTALLATION



INFORMATION

Choosing A Mirror

- > Help Me Choose
- > Distance Chart

Installation

- > Standard
- > Dome
- > Half Dome
- > Quarter Dome
- > Outdoor
- > Vehicle Inspection

Cleaning Guide

- > Acrylic Face
- > Stainless Steel Face

MOUNTING INSTRUCTIONS

1. Decide the appropriate place to site the mirror to give maximum vision.
2. Fix J- Bracket to wall or ceiling using suitable fixing methods i.e. screws, bolts. Allowing enough room to get the mirror on to the J- Bracket.
3. Thread adaptor into the back of the mirror.
4. Note: Adaptors on Deluxe models are already threaded into the back of the mirror.
5. Peel protective film off around the immediate edge of the mirror.
6. Now, by sliding the adaptor and mirror over the J- Bracket, adjust mirror to the desired position.
7. (Note: Outdoor Mirrors - make sure the arrows on the back are pointing UP. This will allow the vent hole in the bottom of the mirror to point down).
8. Once the desired position has been found for maximum vision, tighten locking bolt on the adaptor securely.

ASSEMBLY

